Sygic

SYGIC PROFESSIONAL NAVIGATION

Geotab Add-in User Guide

VEHICLE ATTRIBUTES SETUP

1. In MyGeotab, navigate to the Sygic Truck Settings add-in in the left tab

2. Select one of the existing vehicles by clicking on the edit button on the right side

VEHICLE ATTRIBUTES SETUP

3. Input or change the attributes (width, height, weight, axle weight, length)

4. Click "Apply Changes"

CREATING A ROUTE AND ROUTE PLAN

With Sygic Geotab Drive add-in, you are able to list all assigned route plans.

In order to add plans, follow these steps:

1. Navigate to Zones & Messages – Routes – Routes within MyGeotab.

2. Type an adress or add a route stops.

CREATING A ROUTE AND ROUTE PLAN

3. Define the route

4. Click on "Save route"

CREATING A ROUTE AND ROUTE PLAN

5. In Route Edit, click "Create plan"

CREATING A ROUTE AND ROUTE PLAN

6. Assign the vehicle and fill out all necessary details

CREATING A ROUTE AND ROUTE PLAN

7. Click on the Map section to see all of your routes

7.

For more information on how to manage routes and route plans, please refer to Geotab documentation.

STARTING THE NAVIGATION FROM THE GEOTAB DRIVE APP

1. Open Geotab Drive and in the main dashboard, choose "Start Sygic Truck"

2. Under "My Plans" tap on the desired route to navigate to a single destination or tap on "Open itinerary" to see see the route with all stops.

3. Sygic Truck Navigation will open and automatically set the destination, respecting the assigned vehicle attributes

DRIVE SAFELY WITH SYGIC!

Sygic

www.sygic.com